

Lab 10

```
#include <ESP8266WiFi.h>
#include <ESP8266HTTPClient.h>
#include <WiFiClientSecure.h>

const char* ssid = "TP-LINK_8705FE";
const char* password = "78405608";
const char* thingHTTPOurl =
"https://api.thingspeak.com/apps/thinghttp/send_request?api_key=33WDG1LBPQPFJ00H";

void setup() {
  Serial.begin(115200);
  WiFi.begin(ssid, password);
  Serial.print("Connecting to WiFi");
  while (WiFi.status() != WL_CONNECTED) {
    delay(500);
    Serial.print(".");
  }
  Serial.println("\nConnected!");
}

void loop() {
  if (WiFi.status() == WL_CONNECTED) {
    WiFiClientSecure client;
    client.setInsecure();
    HTTPClient http;
    http.begin(client, thingHTTPOurl);
    int httpCode = http.GET();
    if (httpCode > 0) {
      String payload = http.getString();
      Serial.println("Current Time in Pakistan: " + payload);
    } else {
      Serial.println("Error on HTTP request");
    }
    http.end();
  }
  delay(10000);
}
```

Output:

Apps / ThingHTTP / Request 233179

Edit ThingHTTP

Name:	Request 233179
API Key:	33MDG1LBPQPF300H
	Regenerate API Key
URL:	https://timeapi.io/api/Time/current/zone?timeZone=Asia/Karachi
HTTP Auth Username:	
HTTP Auth Password:	
Method:	GET
Content Type:	
HTTP Version:	1.0
Host:	
Headers:	
Body:	
Parse String:	
Created:	2026-04-23 12:34 pm

Help

You can now send your ThingHTTP request and view the response using the following URL:

GET https://api.thingspeak.com/apps/thinghttp/send_request?api_key=33MDG1LBPQPF300H

[Learn More](#)

OutputSerial Monitor X

Message (Enter to send message to 'NodeMCU 1.0 (ESP-12E Module)' on 'COM11')

New Line115200 baud

Pakistan: {"year":2026,"month":4,"day":23,"hour":18,"minute":23,"seconds":34,"milliseconds":64,"dateTime":"2026-04-23T18:23:34.0642447","date":"04/23/2026","time":"18:23","timeZone":"Asia/Karachi","dayOfWeek":"Thursday","dstActive":false}
Pakistan: {"year":2026,"month":4,"day":23,"hour":18,"minute":23,"seconds":48,"milliseconds":185,"dateTime":"2026-04-23T18:23:48.1856753","date":"04/23/2026","time":"18:23","timeZone":"Asia/Karachi","dayOfWeek":"Thursday","dstActive":false}
Pakistan: {"year":2026,"month":4,"day":23,"hour":18,"minute":24,"seconds":1,"milliseconds":641,"dateTime":"2026-04-23T18:24:01.6414154","date":"04/23/2026","time":"18:24","timeZone":"Asia/Karachi","dayOfWeek":"Thursday","dstActive":false}
Pakistan: {"year":2026,"month":4,"day":23,"hour":18,"minute":24,"seconds":15,"milliseconds":567,"dateTime":"2026-04-23T18:24:15.5677602","date":"04/23/2026","time":"18:24","timeZone":"Asia/Karachi","dayOfWeek":"Thursday","dstActive":false}